



NR.	CODE	DESCRIPTION	QT. CODE
1	883111	INLET VALVE AG104 PLUS 3/8P	
2	882654	INLET VALVE AZOR 3/8" OLIPURE	1
3	011195	BASE FOR PROTECTIVE BOX	1
4	883226	CABLE OUTLET VALVE SEAL 60X26.5X2	5
5	021269	CENTRAL BLOCK	1
6	011150	CONTROL PLATE FIXERS	2
7	021270	FLEXIBLE HOSE 3/8 / 3/8 X 300	1
8	011982	FLUSH PIPE 315	1
9	033313	FLUSH PIPE O-RING Ø55	5
10	021209	FLUSH PIPE SEAL Ø40/45	5
11	021203	INLET VALVE AZOR PLUS 3/8"	1
12	012001	INLET VALVE MEMBRANE AZOR	1
13	011954	INLET VALVE SUPPORT	1
14	033303	LEVER BLOCK	1
15	033125	MECHANIC OUTLET VALVE	1
16	056934	MECHANIC OUTLET VALVE ANCHORS	1
17	181713	OLIPURE KIT	1
18	883224	O-RING VALVE GUIDE	5
19	030484	OUTLET VALVE CABLE	1
20	883028	OUTLET VALVE SEAL 60X23.8X2.7	5
21	033301	PNEUMATIC BLOCK BELLOWS	1
22	033126	PNEUMATIC OUTLET VALVE	1
23	026698	PROTECTIVE BOX >09	1
24	033314	PROTECTIVE PLATE	1
25	021271	PROTECTIVE PLATE >09	1
26	021206	STOP VALVE	1
27	021272	STOP VALVE SUPPORT	1
28	882495	INLET VALVE NANO PLUS 3/8"	1