



NR.	CODE	DESCRIPTION	QT. CODE
1	053871	BASE	1
2	131989	FLUSH PLATE ACTUATION AND FIXATION SCREWS	4
3	053868	MECHANIC COUNTER PLATE	1
4	049963	OUTLET VALVE EXTENSION KIT	10
5	053869	PNEUMATIC COUNTER PLATE	1
6	053865	SPRINGS	10